QUICK REFERENCE
ALTITRON
DIGITAL ALTIMETER



Altimeter View, Meters

Altimeter View, Feet Below 20,000 ft



Altimeter View, Feet Above 20,000 ft



Speedometer View



Warning at Breakoff Altitude




Inflight View, Meters



Inflight View, Feet Below 20,000 ft




Inflight View, Feet Above 20,000 ft



View Temperature



Configuration




Standby Mode

Click Any key




Activate Backlight




Ground or Inflight Mode



Log



Totals




Unit Information

KEY USAGE

Hold Key Until Unit Beeps

Click SELECT and Then the Other Key

MENU


MENU
28-03-09 15:26
3 16
Number of Jump
28-03-09 15:26
38 10 MT
LOG ALTI
Exit Altitude
28-03-09 15:26
78 1 MT
LOG ALTI
Pull Altitude
28-03-09 15:26
65
LOG
Freefall Time
28-03-09 15:26 SPEED KMH
3 18
LOG
Maximum Freefall Speed
28-03-09 15:26 SPEED KMH
2 18
LOG
Average Freefall Speed
28-03-09 15:26
°C 18
LOG
Jump Temperature
CP 15:26
3.28
LOG
Time Under Open Canopy
CP 15:26 SPEED KMH
86
LOG
Maximum Speed Under Open Canopy
Hold To Exit Log
Click or To Browse Log
Hold or To Browse Faster
LOG
MENU
14 23 48
149
Number of Jumps Totalized
14 23 48
4805 MT
ALTI
Highest Exit Altitude
14 23 48
73 1 MT
ALTI
Lowest Pull Altitude
14 23 48 SPEED KMH
3 18
Highest Freefall Speed
Hold To Reset Totals/Logbook
14 23 48
284
LOG CONFIG
TOTALS
MENU
SPEED
ALTI CONFIG
Set Main Function
10 MT
ALTI CONFIG
Configure Altitude Display Resolution
986 MT
ALTI CONFIG
Ground Reference Reset (Inflight Mode Only)
1200 MT
ALTI CONFIG
Set Breakoff Altitude
180 MT
OFFSET CONFIG
Configure Offset
MT FT
CONFIG
Configure Altitude Units
KMH MPH
CONFIG
Configure Speed Units
°C °F
CONFIG
Configure Temperature Units
31-12
CONFIG
Configure Date Format
28-03-09 15:26
CONFIG
Configure Date and Time
Hold To Exit Configuration Mode
CONFIG