



MEN SIZE CHART




HEIGHT

Measure height vertically between the top of the head and the sole, on the person standing straight, feet together.




1 - CHEST

Chest circumference is the largest measurement taken on a person standing, breathing normally, passing the measuring tape horizontally at the chest, below the armpits, arms down.




2 - WAIST

Waist circumference is the measurement taken at the waist (the narrowest point between chest and hips), while breathing normally, on a person standing with relaxed abdomen.




3 - HIPS

Hips circumference is taken horizontally at the widest point of the basin (buttocks).



4 - INSEAM

Inner legs length (from crotch to the ground) is the distance measured along the leg between the lowest part of the bust and the sole on a person standing straight, with feet slightly apart. If the suit has "booties", take measurement with shoes.




5 - ARM LENGTH

It's the distance from the outside of the shoulder to the wrist, along the arm bent.


SIZE	HEIGHT	CHEST (1)	WAIST (2)	HIPS (3)	INSEAM (4)	ARM LENGTH (5)
XS	5'3"/5'6"	36"/37 1/2"	30 3/4"/32 1/4"	35 1/2"/37"	31 1/2"/32 1/4"	24 1/2"/25 1/4"
S	5'6"/5'8"	37 1/2"/39"	32 1/4"/33 3/4"	37"/38 1/2"	32"/32 3/4"	25"/25 1/2"
M	5'8"/5'10"	39"/40 1/2"	33 3/4"/35 1/2"	38 1/2"/40"	32 1/4"/33"	25 1/4"/26"
L	5'10"/6'	40 1/2"/42"	35 1/2"/37"	40"/41 3/4"	32 3/4"/33 1/2"	25 1/2"/26 1/4"
XL	6'/6'1"	42"/43 3/4"	37"/38 1/2"	41 3/4"/43 1/2"	33"/34"	26"/26 3/4"
XXL	6'1"/6'2"	43 3/4"/45 1/4"	38 1/2"/40"	43 1/2"/45"	33 1/2"/34 1/4"	26 1/4"/27"
3XL	6'2"/6'4"	45 1/4"/47"	40"/42"	44"/46 1/2"	33 1/2"/34 1/4"	26 1/4"/27"

WOMEN SIZE CHART




HEIGHT

Measure height vertically between the top of the head and the sole, on the person standing straight, feet together.




1 - CHEST

Chest circumference is the largest measurement taken on a person standing, breathing normally, passing the measuring tape horizontally at the chest, below the armpits, arms down.




2 - WAIST

Waist circumference is the measurement taken at the waist (the narrowest point between chest and hips), while breathing normally, on a person standing with relaxed abdomen.




3 - HIPS

Hips circumference is taken horizontally at the widest point of the basin (buttocks).



4 - INSEAM

Inner legs length (from crotch to the ground) is the distance measured along the leg between the lowest part of the bust and the sole on a person standing straight, with feet slightly apart. If the suit has "booties", take measurement with shoes.



5 - ARM LENGTH

It's the distance from the outside of the shoulder to the wrist, along the arm bent.

SIZE	HEIGHT	CHEST (1)	WAIST (2)	HIPS (3)	INSEAM (4)	ARM LENGTH (5)
XS	5'1"/5'4"	31"/32 ¾"	24 ½"/26"	35"/36 ½"	30"/30 ¾"	22 ½"/23 ¼"
S	5'2"/5'4"	32 ½"/34 ¼"	26"/27 ½"	36 ½"/38"	30 ¾"/31"	23"/23 ½"
M	5'4"/5'6"	34 ¼"/36"	27 ½"/29"	38"/39 ¾"	30 ¾"/31 ½"	23 ¼"/24"
L	5'4"/5'6"	36"/37 ½"	29"/30 ¾"	39 ¾"/41 ¼"	31"/32"	23 ½"/24 ½"
XL	5'6"/5'8"	37 ½"/39"	30 ¾"/32 ¼"	41 ¼"/43"	31 ½"/32 ¼"	24"/24 ¾"
XXL	5'8"/5'9"	39"/40 ½"	32 ¼"/34"	43/44 ½"	32"/32 ½"	24 ½"/25 ¼"
3XL	5'8"/5'10"	40 ½"/42"	34"/35 ½"	44 ½"/46"	32"/32 ½"	24 ½"/25 ¼"